

Technology Room Operation Manual

For assistance, call: 554-3079, 554-3538
or visit: RH 407

1. Use **POWER** switch to turn on the computer
2. Tap the touch screen to activate the system
3. Select the source to be shown on the projector screen
4. Tap *Turn System ON* to start projection
5. To use USB drive, insert drive to the **USB port**
6. To use the floppy disk, insert disk to **Floppy drive**
7. To play CD/DVD, use **CD/DVD drive**
8. To play VHS tape, **Power** on **VCR**
Insert the tape
Use **control buttons** to navigate

